

Speakeasy Vintage Music

122 Leslie Kit Instructions

INTRODUCTION

This kit contains the Speakeasy 122 Console Connector. When properly installed to a Hammond tonewheel console, it provides control and proper connection for model 122 type Leslie tone cabinets (122, 142, 21H, 22H, 222, etc.)

CAUTION: Due to the presence of electrical potential, only an experienced technician should perform installation procedures or adjustments involving 110vac or 220vac "mains" power.

NOTE: The connector chassis should be installed in a location where the wires can reach their destinations. In the event of connecting to a distant outlet (like one in a B3 outlet box) the included pigtail may need to be spliced to the original outlet wiring.

WARNING: Always inspect console wiring to make sure it is in safe and serviceable condition before any accessory installation.

Wire Color	Description	Connection
Blue & Grey Twisted Pair	AC Mains	To Blue and Grey wires on Pre-amp AC panel
Red & Black Twisted Pair	GG Terminals	One to each "G" terminal on Preamp
Yellow	Chassis Ground	Place under a chassis screw
Brown	Speed Switch	Connect to "Half-Moon" or other appropriate SPST switch.